



Logitech Mouse M525 Disassembly

The one thing to hate about Logitech mice is that they hide their screws under the glide pads...

Written By: Stephan





TOOLS:

- [Phillips #2 Screwdriver](#) (1)
-

Step 1 — Remove battery cover.



- Switch for this is on the bottom. Very findable, so no image.

Step 2 — Remove batteries





- And the Unifying receiver, if its in the mouse. This is not strictly needed, but you shold probably still do it.

Step 3 — Find the fixation screws




- They are hidden below the two glide pads on the sides of the release switch for the battery cover. Just stick your Phillips in there and get them out.

Step 4 — Pull down the downside cover



- It will resist a little, gently pull. When you have a little gap, gently rock it for- and backward a little, until it gets loose.
- The second image tries to show the clutches that hold it to the upper cover.

Step 5 — Now you can just remove the rest, like the mouse wheel and stuff.



- Insert wisdom here.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-22 05:22:36 PM.